



- ① Felt pads
- ② Screws
- ③ Premium Feet
- ④ Allen key



1. Attach the individual felt pads ① to each end of the two feet ③. These felt pads will help protect your floor and keep your heater from sliding around.

2. Position the panel between the slots on the feet. Ensure that the holes on the feet for the screws are located at the back of the panel.

3. Use the provided allen key ④ to screw in the screws ②. Start by loosely attaching them to ensure you have the panel properly aligned. Once you're sure it's balanced and positioned correctly, tighten the screws to securely attach the panel to the feet.

